


PH22 2301686 Ver1

TABLE OF CONTENTS

Polehedger Fixed Pipe Assembly	3
Polehedger Head Assembly	5
Pivot Head Assembly	8
Rear Housing Assembly	10
Handle Assembly	12

Polehedqer Fixed Pipe Assembly




Rendered by LeadVenture, Inc.

Polehedger Fixed Pipe Assembly

Ref Number	Part Number	Part Description	Context Notes	Quantity
1	R0211407-00	Fixed Pipe Assembly		1
2	R0210834-00	Harness Buckle		1
3	R0206110-00	Screw With Washers, M5*20		1
4	R0210835-00	Hexagon nuts,style 1		1
5	R0211408-00	Power Cord Assembly		1
6	R0203584-00	Harness		1

Polehedger Head Assembly




Rendered by LeadVenture, Inc.

Polehedger Head Assembly

Ref Number	Part Number	Part Description	Context Notes	Quantity
1	R0210922-00	Hexalobular socket pan head screws		4
2	R0105271-00	Housing Assembly		1
3	R0210919-00	Motor Gear Assembly		1
4	R0210923-00	Screw, M4 x 16 mm		2
5	R0210911-00	Gearbox Assembly		1
6	R0210920-00	Hexalobular socket pan head screws		2
7	R0210913-00	Washer		3
8	R0207249-00	Connecting Rod Assembly		2
9	R0207251-00	Gear Eccentric Block Assembly		1
10	R0210986-00	Blade/Bar Assembly		1
11	R0210916-00	Hexagon head bolt and single coil spring lock washer assemblies		2
12	R0211262-00	Pad,Sealing		1
13	R0210915-00	Gearbox Sealing Gasket		1
14	R0210912-00	Gearbox Cover Assembly		1
15	R0101339-00	Spring Washer, Φ5.1		11
16	R0210925-00	Hexalobular socket pan head screws		2
17	R0210566-00	Screw, Hex M5*15		4
18	R0203472-00	Waterproof Plug		1

Ref Number	Part Number	Part Description	Context Notes	Quantity
19	R0210927-00	Small Micro Switch		1
20	R0210926-00	Pivot Head Cover		1
21	R0206110-00	Screw With Washers, M5*20		5
22	R0105305-00	Blade Sleeve		1
23	R0210942-00	Grease		1

Pivot Head Assembly




Rendered by LeadVenture, Inc.

Pivot Head Assembly

Ref Number	Part Number	Part Description	Context Notes	Quantity
1	R0210797-00	Hexagon Lobular Socket Head Cap Screws And Spring Washer Assemblies		6
2	R0210938-00	Flat Washer		6
3	R0211091-00	Pivot Head Upper Cover		1
4	R0210930-00	Hexagon Lobular Socket Pan Head Screws And Serrated Lock Washer External Teeth A		2
5	R0210931-00	Head Clamp		1
6	R0209452-00	Steel Wire Pin Assembly		1
7	R0210932-00	Rotating Clamp		2
8	R0210939-00	spring		2
9	R0210934-00	Copper Bush		2
10	R0210933-00	Iron Ring		1
11	R0210929-00	Pivot Head Lower Cover Assembly		1
12	R0210940-00	Hexalobular socket pan head screws		1
13	R0210941-00	Torx Flange Screws		1
14	R0105270-00	Pipe Sleeve		1
15	R0210937-00	Spring		1
16	R0210942-00	Grease		1

Rear Housing Assembly




Rendered by LeadVenture, Inc.

Rear Housing Assembly

Ref Number	Part Number	Part Description	Context Notes	Quantity
1	R0210574-00	Screw, Hex ST4.2*16		13
2	R0105275-00	Upper Cover		1
3	R0210974-00	Clamp		1
4	R0105274-00	Housing Assembly		1
5	R0210973-00	Hexagon nuts,style 1		1
6	R0210965-00	Jacket Pipe		1
7	R0210970-00	screw		3
8	R0210968-00	Hexagon socket head cap screws		1
9	R0210584-00	Screw, Hex M6*18		1
10	R0203287-00	Spring Base		1
11	R0210799-00	Reset Spring		3
12	R0105276-00	Battery Box		1
13	R0210964-00	PCB Assembly		1
14	R0210972-00	Parallel pins,of unhardened steel and austenitic stainless steel		2
15	R0210733-00	Battery Pack Release Button Shaft		1
16	R0210798-00	Torsion Spring		1
17	R0105298-00	Release Button		1
18	R0210612-00	Screw, Hex ST4.2*12-F		2
19	R0105309-00	Rear Cover		1

Handle Assembly



Rendered by LeadVenture, Inc.

Handle Assembly

Ref Number	Part Number	Part Description	Context Notes	Quantity
1	R0105273-00	Handle Assembly		1
2	R0210814-00	U-shaped Clamp		2
3	R0210825-00	Hexalobular socket pan head screws		2
4	R0105308-00	Power Button		1
5	R0210818-00	Lockout Spring		1
6	R0105272-00	PCB Assembly		1
7	R0210823-00	Retaining Plate		1
8	R0210826-00	Hexalobular socket pan head tapping screws		1
9	R0105306-00	Lockout Button Assembly		1
10	R0210815-00	Dowel pins		1
11	R0105307-00	Switch Trigger		1
12	R0208609-00	Speed-control Switch		1
13	R0210574-00	Screw, Hex ST4.2*16		6