


T13 T13A1 Ver1

TABLE OF CONTENTS

Rear Handle Assembly	3
String Head Assembly	5
Pole Assembly	7
Guard Assembly	9
Motor Maintenance Assembly	11
Cutting Blade Assembly	13
Rear Housing Assembly	15
String Trimmer Head Assembly	17

Rear Handle Assembly




Rendered by LeadVenture, Inc.

Rear Handle Assembly

Ref Number	Part Number	Part Description	Context Notes	Quantity
1	R0210574-00	Screw, Hex ST4.2*16		6
2	R0105655-00	Handle Assembly		1
3	R0210817-00	Dowel pins		1
4	R0104391-00	Panel Assembly		1
5	R0212373-00	Lockout Push Button		1
6	R0210828-00	Lockout Torsional Spring		1
7	R0210816-00	Dowel pins		1
8	R0210825-00	Hexalobular socket pan head screws		2
9	R0210814-00	U-shaped Clamp		2
10	R0105308-00	Power Button		1
11	R0210815-00	Dowel pins		1
12	R0105307-00	Switch Trigger		1
13	R0210818-00	Lockout Spring		1
14	R0208609-00	Speed-control Switch		1
15	R0210823-00	Retaining Plate		1
16	R0210826-00	Hexalobular socket pan head tapping screws		1

String Head Assembly




Rendered by LeadVenture, Inc.

String Head Assembly

Ref Number	Part Number	Part Description	Context Notes	Quantity
1	R0212210-00	String Head Seat		1
2	R0213156-00	String Head Spool Cover		1
3	R0213083-00	String Head Seat Assembly		1
4	R0212204-00	Spool Assembly		1
5	R0212225-00	Retaining Block		1
6	R0212208-00	Spring		1
7	R0212198-00	Trimmer head		1

Pole Assembly




Rendered by LeadVenture, Inc.

Pole Assembly

Ref Number	Part Number	Part Description	Context Notes	Quantity
1	R0210833-00	Hexagon lobular socket head cap screws-- Property class 10.9		2
2	R0210832-00	Auxiliary Handle		1
3	R0105770-00	Harness Assembly		1
4	R0214724-00	Pole Assembly		1
5	R0212188-00	Adjusting Rod		1
6	R0210835-00	Hexagon nuts,style 1		1
7	R0105652-00	Harness Buckle		1
8	R0206110-00	Screw With Washers, M5*20		1

Guard Assembly




Rendered by LeadVenture, Inc.

Guard Assembly

Ref Number	Part Number	Part Description	Context Notes	Quantity
1	R0210849-00	Hexagon Lobular Socket Head Cap Anti-detaching Screw		2
2	R0106065-00	Guard		1
3	R0210847-00	Blade		1
4	R0210775-00	Hexagon lobular socket head cap screws--Property class 10.9		1

Motor Maintenance Assembly




Rendered by LeadVenture, Inc.

Motor Maintenance Assembly

Ref Number	Part Number	Part Description	Context Notes	Quantity
1	R0210795-00	Hexalobular socket pan head tapping screws		4
2	R0213589-00	Volute Housing Assembly		1
3	R0213590-00	Motor		1
4	R0213591-00	Motor Jacket Pipe		1
5	R0210797-00	Hexagon Lobular Socket Head Cap Screws And Spring Washer Assemblies		4
6	R0210970-00	screw		3
7	R0211284-00	Hexalobular socket pan head screws		1

Cutting Blade Assembly




Rendered by LeadVenture, Inc.

Cutting Blade Assembly

Ref Number	Part Number	Part Description	Context Notes	Quantity
1	R0106066-00	Guard		1
2	R0104269-00	Cutting Blade		1
3	R0211298-00	Cutting Blade Retaining Plate		1
4	R0212190-00	Nut Cap		1
5	R0212189-00	□□□□□□□		1
6	R0211640-00	Internal?Hexagonal? Wrench		1

Rear Housing Assembly




Rendered by LeadVenture, Inc.

Rear Housing Assembly

Ref Number	Part Number	Part Description	Context Notes	Quantity
1	R0210574-00	Screw, Hex ST4.2*16		9
2	R0210970-00	screw		2
3	R0106063-00	Left and Right Housing Assembly		1
4	R0106064-00	Air Inlet Fence		1
5	R0213594-00	PCBA, Main Controller		1
6	R0210720-00	Fixed Seat		1
7	R0210799-00	Reset Spring		3
8	R0203287-00	Spring Base		1
9	R0105298-00	Release Button		1
10	R0210798-00	Torsion Spring		1
11	R0210733-00	Battery Pack Release Button Shaft		1
12	R0106062-00	Upper Cover		1

String Trimmer Head Assembly



Rendered by LeadVenture, Inc.

String Trimmer Head Assembly

Ref Number	Part Number	Part Description	Context Notes	Quantity
1	R0210566-00	Screw, Hex M5*15		2
2	R0210326-00	Inner Torx Hex Head Bolts, M6*25		1
3	R0213586-00	Rubber Plug		1
4	R0213587-00	Fixed Plate Assembly		1
5	R0213588-00	Gearbox Assembly		1
6	R0210850-00	Conencting Piece		1